This room contains two projectors, a built-in PC, HDMI connection for personal devices, Via Go wireless collaboration, and video conference equipment. The equipment is controlled by a touch panel interface at the instructor station.

System On

Touch the panel to wake it and press the ON button.

If the panel is already on, use the Projector Controls on the left side to turn the projectors on.

Wait 60 seconds for the projectors to power up. The system starts with the PC screen displayed.

Use the PC

- 1. Move the mouse or press a keyboard key to wake the PC. If nothing displays on the monitor:
 - a. Check if the monitor power is on.
 - b. Check if the PC power is on.
- 2. Sign in with your VIU credentials.
- 3. Select a projector at the top of the touch panel.
- 4. Select **PC** on the touch panel.
- 5. Control volume on the PC and/or right side of touch panel.

Connect your own device

An HDMI cable is located at the instructor station.

- 1. Ensure your device is powered on.
- 2. Plug the HDMI cable into your device.
- 3. Select a projector at the top of the touch panel.
- 4. Select HDMI on the touch panel.

If the picture doesn't appear:

Windows: Press **#** + P to select a presentation option (usually Duplicate). **Mac:** Go to System > Preferences > Display > Arrangement > Mirror.

If you still see a black screen, toggle the Black Screen button on the touch screen.



Press the System Off button on the touch panel and confirm shutdown.

Wait 60 seconds before powering on again.

Please turn the AV System off before leaving the room. Sign out of the PC, but do not turn it off.



System







Wireless collaboration

- 1. Connect your device to the **viu-secure** wireless network.
- 2. Select a projector at the top of the touch panel.
- 3. Select VIA GO on the touch panel.
- 4. Repeat for the other projector if necessary.
- 5. Follow prompts on the screen to connect.

Use Zoom video conferencing

This room is equipped with overhead microphones and two cameras (front and rear) for video conferencing.

- 1. Sign in on the PC and open Zoom.
- 2. Sign in to Zoom with SSO and enter "viu" as your domain.
- 3. Enter your VIU Computer Account credentials.
- 4. Set the input on the touch panel to PC to see the camera controls.
 - a. You may need to turn the cameras on with the power button at the top left of the camera controls.
- 5. Create or join a meeting.

If you're experiencing any audio or video issues, go to Zoom settings and confirm the following:

- Video Camera: EasyIP Mixer.
- Audio Speaker: Extron HDMI
- Audio Microphone: Echo Cancelling Speakerphone



This is a dual mode classroom. The camera settings have been customized for specific classes and faculty who teach in this room.

Please do not change the default settings on the projectors or cameras.